Barre porta tutto per furgoni - applicabilità / Van roof bars - application list

23/06/2017





			atlantic		* atlantic.pro		** atlantic.prowork	
VAN MODEL	YEAR	N.°	ACC Roofbars	ALU Roofbars	Side Profile	Connection kit 69.005	Load Basket Bars ACC	Load Basket Bars ALU
CITROEN								
Berlingo (No rails, Barra anteriore-centrale-posteriore)	2009>	3	63.030	62.030	C		69.107	69.007
Berlingo	2009>	3	63.030	62.030	C		69.107	69.007
Jumper (Passo corto 2850 mm, Tetto basso)	>2006	3	63.011	62.011	A+B	•	69.109	69.009
Jumper (Passo medio 3200 mm, Tetto basso)	>2006	3	63.011	62.011	A+B	•	69.109	69.009
Jumper (Passo lungo 3700 mm, Tetto alto)	>2006	4	63.010	62.011	A+B	•	69.109	69.008
Jumper (Passo 3000 mm, Tetto basso)	2006>	3	63.011	62.011	A+B	•	69.109	69.009
Jumper (Passo 3450 mm, Tetto basso)	2006>	3	63.011	62.011	A+B	•	69.109	69.009
Jumper (Passo 3450 mm, Tetto medio)	2006>	3	63.011	62.011	A+C	•	69.109	69.009
Jumper (Passo 4035 mm, Tetto medio)	2006>	4	63.011	62.011	B+C	•	69.109	69.009
Jumper (Passo 4035 mm XL, Tetto medio)	2006>	4	63.011	62.011	C+C	•	69.109	69.009
Jumpy	>2006	3	63.040	62.040	C		69.106	69.006
Jumpy	2007>	3	63.002	62.002	A+A	•	69.107	69.007
Jumpy (Tetto alto)	2007>	3	63.001	62.001	A+A	•	69.106	69.006
Nemo (No rails, Barra anteriore-centrale-posteriore)	2008>	3	63.030	62.030	B		69.107	69.007
DACIA								
Dokker (Barra anteriore-centrale-posteriore)	2013>	3	63.001	62.001	C		69.106	69.006
FIAT								
Doblò (Barra anteriore-centrale-posteriore)	>2009	2/3	63.001	62.001	B		69.106	69.006
Doblò (No rails, Barra anteriore-posteriore)	2010>	2	63.030	62.030	C		69.107	69.007
Doblò (No rails, Barra centrale)	2010>	1	63.002	62.002	C		69.107	69.007
Doblò Maxi (Barra anteriore-centrale-posteriore)	>2009	3	63.001	62.001	C		69.106	69.006
Doblò Maxi (No rails, Barra anteriore-posteriore)	2010>	2	63.030	62.030	C		69.107	69.007
Doblò Maxi (No rails, Barra centrale)	2010>	1	63.002	62.002	C		69.107	69.007
Ducato (Passo corto 2850 mm, Tetto basso)	94-06	3	63.011	62.011	A+B	•	69.109	69.009
Ducato (Passo medio 3200 mm, Tetto basso)	94-06	3	63.011	62.011	A+B	•	69.109	69.009
Ducato (Passo lungo 3700 mm, Tetto alto)	94-06	4	63.010	62.011	A+B	•	69.109	69.008
Ducato (Passo 3000 mm, Tetto basso)	2006>	3	63.011	62.011	A+B	•	69.109	69.009
Ducato (Passo 3450 mm, Tetto basso)	2006>	3	63.011	62.011	A+B	•	69.109	69.009
Ducato (Passo 3450 mm, Tetto medio)	2006>	3	63.011	62.011	A+B	•	69.109	69.009
Ducato (Passo 4035 mm, Tetto medio)	2006>	4	63.011	62.011	B+C	•	69.109	69.009
Ducato (Passo 4035 mm XL, Tetto medio)	2006>	4	63.011	62.011	C+C	•	69.109	69.009
Fiorino (Senza giraffone, Barra anteriore-centrale-posteriore)	1994>	2/3	63.033	62.033	C		69.106	69.006
Fiorino (No rails, Barra anteriore-centrale-posteriore)	2008>	3	63.030	62.030	B		69.107	69.007
Qubo (No rails, Barra anteriore-centrale-posteriore)	2008>	3	63.030	62.030	B		69.107	69.007
Scudo	>2006	3	63.040	62.040	C		69.106	69.006

* Atlantic.pro = allestimento ottenuto dalla combinazione di barre Atlantic e sponde laterali

** Atlantic.prowork = allestimento ottenuto dalla combinazione di barre Atlantic, sponde laterali e barre trasversali

* Atlantic.Pro = fitting achieved by matching Atlantic bars with Side profiles

** Atlantic.ProWork = fitting achieved by matching Atlantic bars with Side bars and Transverse profile

Barre porta tutto per furgoni - applicabilità / Van roof bars - application list





			atlantic		* atlantic.pro		** atlantic.prowork	
VAN MODEL	YEAR	N.°	ACC Roofbars	ALU Roofbars	Side Profile	Connection kit 69.005	Load Basket Bars ACC	Load Basket Bars ALU
Scudo	2007>	3	63.002	62.002	A+A	•	69.107	69.007
Scudo (Tetto alto)	2007>	3	63.001	62.001	A+A	•	69.106	69.006
FORD								
Tourneo Connect Vetrato (Glass Roof)	>2013	2	63.001	62.001	C		69.106	69.006
Tourneo Custom Vetrato (Glass Roof)	2012>	3	63.002	62.002	A+A	•	69.107	69.007
Transit Connect	>2013	2	63.001	62.001	C		69.106	69.006
Transit Connect	2014>	4	63.033	62.033	C		69.106	69.006
Transit L2/H2	2014>	3	63.031	62.031	A+A	•	69.108	69.008
Transit Custom (Barra anteriore-centrale-posteriore)	2012>	3	63.002	62.002	A+A	•	69.107	69.007
Transit L3/H2	2014>	4	63.031	62.031	B+B	•	69.108	69.008
Transit L2/H3	2014>	3	63.031	62.031	A+A	•	69.108	69.008
Transit L3/H3	2014>	4	63.031	62.031	B+B	•	69.108	69.008
Transit L4/H3	2014>	4	63.031	62.031	C+C	•	69.108	69.008
HYUNDAI								
H1	ALL	2	63.030	62.030	A+A	•	69.107	69.007
IVECO								
Daily (Passo corto 2850 mm, Tetto basso)	1999>	3	63.020	62.020	A+A	•	69.107	69.007
Daily (Passo medio 3200 mm, Tetto basso)	1999>	3	63.020	62.020	A+B	•	69.107	69.007
Daily (Passo lungo 3700 mm, Tetto alto)	1999>	4	63.020	62.020	B+B	•	69.107	69.007
MERCEDES								
Citan (No rails, Barra anteriore-posteriore)	2012>	2	63.001	62.001	B		69.106	69.006
Citan Maxi (No rails, Barra anteriore-centrale-posteriore)	2012>	2/3	63.001	62.001	C		69.106	69.006
Sprinter (Passo corto, Tetto normale)	2006>	3	63.032	62.032	A+B	•	69.109	69.009
Sprinter (Passo lungo, Tetto alto)	2006>	5	63.031	62.031	C+C	•	69.108	69.008
Sprinter (Passo lungo, Tetto alto con sbalzo lungo)	2006>	6	63.031	62.031	C+C	•	69.108	69.008
Sprinter (Passo medio, Tetto alto)	2006>	3	63.031	62.031	A+C	•	69.108	69.008
Sprinter (Passo medio, Tetto normale)	2006>	3	63.032	62.032	A+C	•	69.109	69.009
Vito	04-07	4	63.031	62.031	A+A	•	69.108	69.008
Vito	2008>	3	63.031	62.031	A+A	•	69.108	69.008
NISSAN								
NV 200 (Barra anteriore-centrale-posteriore)	2009>	2/3	63.001	62.001	C		69.106	69.006
NV 400 L1/H1	2010>	3	63.031	62.031	A+B	•	69.108	69.008
NV 400 L1/H2	2010>	3	63.030	62.030	A+B	•	69.107	69.007
NV 400 L2/H2	2010>	4	63.030	62.030	B+B	•	69.107	69.007
NV 400 L2/H3	2010>	4	63.030	62.030	B+B	•	69.107	69.007
NV 400 L3/H2	2010>	4	63.030	62.030	B+C	•	69.107	69.007

* Atlantic.pro = allestimento ottenuto dalla combinazione di barre Atlantic e sponde laterali

** Atlantic.prowork = allestimento ottenuto dalla combinazione di barre Atlantic, sponde laterali e barre trasversali

* Atlantic.Pro = fitting achieved by matching Atlantic bars with Side profiles

** Atlantic.ProWork = fitting achieved by matching Atlantic bars with Side bars and Transverse profile

Barre porta tutto per furgoni - applicabilità / Van roof bars - application list





VAN MODEL	YEAR	N.°	atlantic ACC Roofbars	atlantic ALU Roofbars	* atlantic.pro Side Profile	* atlantic.pro Connection kit 69.005	** atlantic.prowork Load Basket Bars ACC	** atlantic.prowork Load Basket Bars ALU
NV 400 L3/H3	2010>	4	63.030	62.030	B+C	•	69.107	69.007
NV 400 L4/H2	2010>	4	63.030	62.030	C+C	•	69.107	69.007
NV 400 L4/H3	2010>	4	63.030	62.030	C+C	•	69.107	69.007
Evalia	2012>	2/3	63.001	62.001	C		69.106	69.006
Interstar (Passo corto, Tetto alto)	99-10	3	63.030	62.030	A+B	•	69.107	69.007
Interstar (Passo corto, Tetto basso)	99-10	3	63.032	62.032	A+B	•	69.109	69.009
Interstar (Passo lungo, Tetto alto)	99-10	4	63.030	62.030	B+B	•	69.107	69.007
Interstar (Passo medio, Tetto alto)	99-10	3	63.030	62.030	B+B	•	69.107	69.007
Kubistar (Barra anteriore-posteriore)	03-09	2	63.001	62.001	C		69.106	69.006
Primastar (Attenzione!! No barra sopra cabina)	>2014	3	63.031	62.031	A+A	•	69.108	69.008
Primastar	2014>	4	63.031	62.031	A+A	•	69.108	69.008
OPEL								
Combo (Attenzione!! Versione con fori sul tetto)	1994>	2	63.033	62.033	B		69.106	69.006
Combo (Barra anteriore-posteriore)	2012>	2	63.030	62.030	C		69.107	69.007
Combo (Barra centrale)	2012>	1	63.002	62.002	C		69.107	69.007
Movano (Passo corto, Tetto alto)	99-10	3	63.030	62.030	A+B	•	69.107	69.007
Movano (Passo corto, Tetto basso)	99-10	3	63.032	62.032	A+B	•	69.109	69.009
Movano (Passo lungo, Tetto alto)	99-10	4	63.030	62.030	B+B	•	69.107	69.007
Movano (Passo medio, Tetto alto)	99-10	3	63.030	62.030	B+B	•	69.107	69.007
Movano L1/H1	2010>	3	63.031	62.031	A+B	•	69.108	69.008
Movano L1/H2	2010>	3	63.030	62.030	A+B	•	69.107	69.007
Movano L2/H2	2010>	4	63.030	62.030	B+B	•	69.107	69.007
Movano L2/H3	2010>	4	63.030	62.030	B+B	•	69.107	69.007
Movano L3/H2	2010>	4	63.030	62.030	B+C	•	69.107	69.007
Movano L3/H3	2010>	4	63.030	62.030	B+C	•	69.107	69.007
Movano L4/H2	2010>	4	63.030	62.030	C+C	•	69.107	69.007
Movano L4/H3	2010>	4	63.030	62.030	C+C	•	69.107	69.007
Vivaro (Attenzione!! No barra sopra cabina)	>2014	3	63.031	62.031	A+A	•	69.108	69.008
Vivaro	2014>	4	63.031	62.031	A+A	•	69.108	69.008
PEUGEOT								
Bipper (No rails, Barra anteriore-centrale-posteriore)	2006>	3	63.030	62.030	B		69.107	69.007
Boxer (Passo corto 2850 mm, Tetto basso)	>2006	3	63.011	62.011	A+B	•	69.109	69.009
Boxer (Passo medio 3200 mm, Tetto basso)	>2006	3	63.011	62.011	A+B	•	69.109	69.009
Boxer (Passo lungo 3700 mm, Tetto alto)	>2006	4	63.010	62.011	A+B	•	69.109	69.008
Boxer (Passo 3000 mm, Tetto basso)	2006>	3	63.011	62.011	A+B	•	69.109	69.009
Boxer (Passo 3450 mm, Tetto basso)	2006>	3	63.011	62.011	A+B	•	69.109	69.009

* Atlantic.pro = allestimento ottenuto dalla combinazione di barre Atlantic e sponde laterali

** Atlantic.prowork = allestimento ottenuto dalla combinazione di barre Atlantic, sponde laterali e barre trasversali

* Atlantic.Pro = fitting achieved by matching Atlantic bars with Side profiles

** Atlantic.ProWork = fitting achieved by matching Atlantic bars with Side bars and Transverse profile

Barre porta tutto per furgoni - applicabilità / Van roof bars - application list





VAN MODEL	YEAR	N.°	atlantic ACC Roofbars	atlantic ALU Roofbars	* atlantic.pro Side Profile	* atlantic.pro Connection kit 69.005	** atlantic.prowork Load Basket Bars ACC	** atlantic.prowork Load Basket Bars ALU
Boxer (Passo 3450 mm, Tetto medio)	2006>	3	63.011	62.011	A+C	•	69.109	69.009
Boxer (Passo 4035 mm, Tetto medio)	2006>	4	63.011	62.011	B+C	•	69.109	69.009
Boxer (Passo 4035 mm XL, Tetto medio)	2006>	4	63.011	62.011	C+C	•	69.109	69.009
Expert	>2006	3	63.040	62.040	C		69.106	69.006
Expert	2007>	3	63.002	62.002	A+A	•	69.107	69.007
Expert (Tetto alto)	2007>	3	63.001	62.001	A+A	•	69.106	69.006
Partner (No rails, Barra anteriore-centrale-posteriore)	2009>	3	63.030	62.030	C		69.107	69.007
RENAULT								
Kangoo (Barra anteriore-posteriore)	97-07	2	63.001	62.001	C		69.106	69.006
Kangoo (No rails, Barra anteriore-posteriore)	2008>	2	63.001	62.001	C		69.106	69.006
Kangoo Maxi (No rails, Barra anteriore-centrale-posteriore)	2008>	3	63.001	62.001	C		69.106	69.006
Master (Passo corto, Tetto alto)	99-10	3	63.030	62.030	A+B	•	69.107	69.007
Master (Passo corto, Tetto basso)	99-10	3	63.032	62.032	A+B	•	69.109	69.009
Master (Passo lungo, Tetto alto)	99-10	4	63.030	62.030	B+B	•	69.107	69.007
Master (Passo medio, Tetto alto)	99-10	3	63.030	62.030	B+B	•	69.107	69.007
Master L1/H1	2010>	3	63.031	62.031	A+B	•	69.108	69.008
Master L1/H2	2010>	3	63.030	62.030	A+B	•	69.107	69.007
Master L2/H2	2010>	4	63.030	62.030	B+B	•	69.107	69.007
Master L2/H3	2010>	4	63.030	62.030	B+B	•	69.107	69.007
Master L3/H2	2010>	4	63.030	62.030	B+C	•	69.107	69.007
Master L3/H3	2010>	4	63.030	62.030	B+C	•	69.107	69.007
Master L4/H2	2010>	4	63.030	62.030	C+C	•	69.107	69.007
Master L4/H3	2010>	4	63.030	62.030	C+C	•	69.107	69.007
Trafic (Attenzione!! No barra sopra cabina)	01-14	3	63.031	62.031	A+A	•	69.108	69.008
Trafic	2014>	4	63.031	62.031	A+A	•	69.108	69.008
VOLKSWAGEN								
Caddy (Barra anteriore-posteriore)	2004>	2	63.001	62.001	B		69.106	69.006
Caddy Maxi (Barra anteriore-centrale-posteriore)	2004>	3	63.001	62.001	C		69.106	69.006
Caravelle	2004>	4	63.031	62.031	A+B	•	69.108	69.008
Crafter (Passo corto, Tetto normale)	2006>	3	63.032	62.032	A+B	•	69.109	69.009
Crafter (Passo lungo, Tetto alto)	2006>	5	63.031	62.031	C+C	•	69.108	69.008
Crafter (Passo lungo, Tetto alto con sbalzo lungo)	2006>	6	63.031	62.031	C+C	•	69.108	69.008
Crafter (Passo medio, Tetto alto)	2006>	3	63.031	62.031	A+C	•	69.108	69.008
Crafter (Passo medio, Tetto normale)	2006>	3	63.032	62.032	A+C	•	69.109	69.009
Transporter	2004>	4	63.031	62.031	A+B	•	69.108	69.008

* Atlantic.pro = allestimento ottenuto dalla combinazione di barre Atlantic e sponde laterali
** Atlantic.prowork = allestimento ottenuto dalla combinazione di barre Atlantic, sponde laterali e barre trasversali
* Atlantic.Pro = fitting achieved by matching Atlantic bars with Side profiles
** Atlantic.ProWork = fitting achieved by matching Atlantic bars with Side bars and Transverse profile